

COLE TYPE L

Copper Center Break Disconnect Switch

For 8.3 – 72.5 kV Ratings

INSTALLATION &

INSTRUCTION

MANUAL



Page I



Safety Information

IMPROPER HANDLING, INSTALLATION, OPERATION OR MAINTENANCE OF THIS EQUIPMENT MAY CAUSE IMMEDIATE HAZARDS WHICH WILL LIKELY RESULT IN SERIOUS PERSONNEL INJURY OR DEATH.

The equipment covered by this publication must be handled, installed, operated and maintained by qualified persons who have direct knowledge and experience dealing with the hazards involved and are thoroughly trained in the handling, installation, operation and maintenance of high voltage transmission and distribution equipment. These instructions are meant for only such **Qualified Persons**. They are not intended to be a substitute for adequate training and experience in safety procedures for this type of equipment.

A Qualified Person is one who is trained in and has skills necessary:

- to read and comprehend this instruction book understanding that these instructions are general in nature
- to accept personal responsibility to prepare and maintain an intrinsically safe work environment and maintain control of the work site to safeguard all persons present
- to develop and implement a proper rigging, lifting, and installation plan along with all safety
 precautions required to insure safe and proper lifting and installation of the equipment.
- to distinguish between energized and non energized parts
- · to determine proper approach distances to energized parts
- to properly work with and around energized or de-energized equipment that may be pressurized with gas
- for proper use of personal protective equipment, insulating and shielding materials, insulated tools for working near energized and /or pressurized electrical equipment
- to recognize and take necessary precautions for the unique and dynamic conditions of site and specialized equipment to maintain a safe work environment during handling, installation, operation, and maintenance of high voltage switching equipment

The instructions in this manual are general guidelines for this type of equipment and not specific to the equipment supplied. Portions of it may not be applicable or may not have complete instructions for your specific equipment.

If you do not understand any part of these instructions or need assistance, contact Southern States Service Division at 770-946-4562 during normal business hours (EST) or 770-946-4565 after normal business hours.



LIMITED WARRANTY

Southern States, LLC ("SSLLC") warrants only to the Warranty Holder (hereinafter defined as the "End User" or the "Immediate Purchaser", as applicable, pursuant to the terms and conditions of this Limited Warranty as set forth below), that the Product identified below will, upon shipment, be free of defects in workmanship and material for the applicable Warranty Period. The "Warranty Period" is that period of time during which this Limited Warranty is effective, and such period begins on the invoice date issued by SSLLC for the Product, and continues until the earlier to occur of (1) the expiration of the Warranty Duration period, or (2) the Number of Operations, both as specified in the table below. If the Product is both purchased and installed within the United States or Canada, this Limited Warranty is granted to each end user of the Product who acquired the Product for its own use during the Warranty Period ("End User"). In all other situations, this Limited Warranty is granted only to the first purchaser of the Product ("Immediate Purchaser") from SSLLC. No primary or remote purchaser or owner of the Product who is not a Warranty Holder may claim any benefit under this Limited Warranty, or any remedial promise included in this Limited Warranty. SSLLC shall, upon prompt written notice from the Warranty Holder, correct a nonconforming Product by repair or replacement at the sole discretion of SSLLC of the nonconforming Product or any part or component of a nonconforming Product necessary in SSLLC's discretion to make such Product conforming. Any transportation charges, labor for removing, reinstalling the Product or part, and/or costs related to providing access to the Product shall be the responsibility of the Warranty Holder. Correction in this manner will constitute the Warranty Holder's exclusive remedy and fulfillment of all SSLLC's liabilities and responsibilities hereunder. SSLLC's duty to perform under this limited warranty may be delayed, at SSLLC's sole option, until SSLLC has been paid in full for all products purchased by the Warranty Holder. No such delay will extend the Warranty Period. If SSLLC does not make such repair or replacement, SSLLC's liability for damages on account of any claimed nonconformity will in no event exceed the purchase price of the Product in question. This Limited Warranty does not apply to any Product that has been disassembled, repaired, or altered by anyone other than SSLLC. This Limited Warranty will not apply to any Product that has been subjected to improper or abnormal use of the Product. SSLLC has no responsibility to repair or replace any Product or component thereof manufactured by another party, but SSLLC will assign, to the extent assignable, to the Warranty Holder any manufacturers' warranty that applies to products and components not manufactured by SSLLC.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES. THERE ARE NO OTHER EXPRESS, IMPLIED, OR STATUTORY WARRANTIES. ALL IMPLIED WARRANTIES WHICH MAY ARISE BY IMPLICATION OF LAW, OR APPLICATION OF COURSE OF DEALING OR USAGE OF TRADE, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT OR OTHERWISE ARE EXPRESSLY EXCLUDED. SSLLC SHALL NOT BE LIABLE OR RESPONSIBLE FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, EXEMPLARY, SPECIAL, OR PUNITIVE DAMAGES, EVEN IF SSLLC HAS BEEN ADVISED OF THE POSSIBILITY OF SAME. THE WARRANTY HOLDER IS SOLELY RESPONSIBLE FOR THE SUITABILITY OF THE PRODUCT FOR ANY PARTICULAR APPLICATION.

Product Purchased Region	Product Installed Region	Warranty Holder	Warranty Duration
U.S and Canada	U.S and Canada	End User	Five (5) Years
All Other Conditions		Immediate Purchaser	Earlier of 1 year from installation or 18 months from shipment

States

Southern

<u>Southern States, LLC</u>

Equipment Receipt, Installation, Use, Operation and Maintenance Terms

("Terms of Use")

The purchaser ("Purchaser") of certain Equipment (the "Equipment") identified in the Instruction Manual accompanying these Terms of Use sold by Southern States, LLC ("Southern States"), by Purchaser's acceptance or Use of Equipment in any way, agrees to the Terms of Use set forth below (the word "Use" herein means receipt, testing, inspection, installation, operation, maintenance and otherwise handling the Equipment):

- Purchaser represents and warrants that it is fully qualified to Use the Equipment, and that it is a sophisticated user of the Equipment with a high level of expertise in the Use of the Equipment and Purchaser knows that Southern States is relying on Purchaser's sophistication and expertise with respect to the Equipment.
- The Purchaser will, within seven (7) days after receipt of the Equipment, inspect the Equipment and identify and notify Southern States in writing of any missing parts, damage or defects observed in the Equipment.
- The Purchaser will Use the Equipment, only in conformity with all manuals, data sheets and instructions provided by Southern States, and in keeping with sound engineering, utility and safety practice. Purchaser will at its own expense, provide all necessary labor, supplies, and facilities required to Use the Equipment.
 - o The Purchaser may use its own personnel or engage a third party to Use the Equipment. The Purchaser shall insure that it only utilizes personnel who are fully qualified or certified by a reputable certification agency to Use the Equipment. In the event that Purchaser cannot find such qualified personnel, the Purchaser will notify Southern States and seek its advice to determine a mutually agreeable solution.
 - By separate agreement, Southern States may provide such services and the personnel to conduct such services in connection with the installation of the Equipment. In the event Southern States agrees to provide personnel to install, maintain, and operate the Equipment, such personnel will function only in an advisory capacity and shall have no responsibility for the supervision, or the quality or workmanship of such installation, maintenance, or operation of the Equipment.
- The Purchaser shall not install and operate the Equipment in a way such that a single point of Equipment failure leads to a cascading event or consequential damage to any person or property. Purchaser shall ensure redundancy in its system at all times. Purchaser acknowledges and agrees that electric service is by nature subject to interruptions due to Equipment failures and shall not agree to provide service free from the effects of Equipment failures.
- The Equipment will be maintained and inspected as provided by this instruction manual and in compliance with best industry practices, but in no event will the Equipment be inspected and tested less frequently than once in every 6 months.

- The Purchaser shall not repair, dismantle, or alter any of the Equipment without Southern States' written consent.
- Any failure of Equipment either in service, testing or inspection will be promptly reported in writing to Southern States within 24 hours of the failure so that adequate evidence can be collected, appropriate diagnostic tests can be conducted, and analysis of the failure can be determined.
- Southern States will have no liability for any direct, indirect, consequential or remote damage or injury, whether or not foreseen or foreseeable, to the Purchaser or any third party or person for any damages or injury to person or property caused by Purchaser's or any third party's actions, whether or not negligent, in the Use of the Equipment. Purchaser shall indemnify and hold Southern States and its employees, officers and directors against any damage or injury caused in whole or part by Purchaser's or any third party's action whether or not negligent, resulting from the Use of the Equipment. Southern States expressly rejects any liability to third parties. The Purchaser expressly waives any claim against Southern States, its employees, officers, directors and affiliates, for injury or damage to person or property resulting from Use of the Equipment not directly and solely caused by Southern States' negligence. For the purposes of clarity, Southern States shall not be liable, and be fully indemnified by the Purchaser, for the following related to the Equipment: normal wear and tear, excessive use and loading, improper interference or maintenance on the part of the Purchaser or third parties, incomplete or false information given by the Purchaser, inappropriate or improper Use, faulty operation, installation or start-up, faulty or careless handling, improper maintenance, use of unsuitable operating materials/substitute materials, defective construction work, hazardous ambient conditions unknown to the Purchaser, chemical, electro-chemical or electrical influences, changes to the subject of delivery made without Southern States consent.
- In the event that Southern States is found by a court of competent jurisdiction or a properly empaneled arbitral body to be liable to the Purchaser for any reason, Southern States shall be entitled to a reduction in the liability by taking into account the exceptions provided by statute, law, and any counterclaims Southern States may have against Purchaser.
- The failure of Purchaser to comply with these Terms of Use herein shall void any and all warranties related to the Equipment. These Terms of Use shall be deemed to be part of the binding contractual agreements between Purchaser and Southern States related to the Equipment and shall govern over any inconsistent term or provision in such other contractual agreements.



Page V



Type L 8.3 – 72.5 kV





Table of Contents

<u>Chapter</u>

<u>Chapter</u>	Page
Table of Contents	VII
List of Tables and Figures	VIII
Summary & Introduction	1
Summary	1
Important	1
Introduction	2
Ratings	3
Product Description	4
Typical Disconnect Switch	4
Receiving, Handling & Storage	5
Unpacking	5
Storage	5
Installation & Adjustment Procedures	6
Recommended Tools & Values	6
Preferred Switch Assembly Method:	7
Operating Mechanism	9
Final Switch Adjustments (Tuning):	10
Changing Disconnect Opening Direction	14
Recommended Inspection Maintenance	16
Patrolling Inspection (6 Months)	17
Routine Inspection and Maintenance (5 year)	17
Periodic Inspection and Maintenance (10 year)	



List of Tables and Figures

Tables Page Table 1: Ratings Table 3 Table 2: Recommended Tools and Torque Values 6 Table 3: Recommended Installation and Maintenance Table 16 Figures Page Figure 1: Type L 69kV, 1600 amp. 4 Figure 2: Insulator Attachment. 7 Figure 3: Mounting Live Parts. 7 Figure 4: Blade Clearance (A=B) 8

Figure 3: Mounting Live Parts	
Figure 4: Blade Clearance (A=B)	8
Figure 5: Typical Operating Arrangement	9
Figure 6: Type HOGO (High Output Geared Operator) Front View	. 10
Figure 7: Type SEGO (Safety Enhanced Gear Operator)	.11
Figure 8: Adjustable Arm Assembly	.13



Page 1 of 17 Summary & Introduction

Summary & Introduction

Summary

These instructions do not intend to cover all details or variations in equipment, or provide for every possible contingency to be met in connection with installation, operation or maintenance. Should information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local Southern States Representative.

The contents of this instruction manual should not become part of or modify any prior or existing agreement, commitment or relationship. The sales contract contains the entire obligations of Southern States. The Warranty contained in the contract between the parties is the sole warranty of Southern States. Any statements contained herein do not create new warranties or modify the existing warranty.

Important

The information contained herein is general in nature and not intended for specific application purposes. It does not relieve the user of responsibility to use sound practices in application, installation, operation, and maintenance of the equipment purchased. Southern States reserves the right to make changes in the specifications shown herein or to make improvements at any time without notice or obligations. Should a conflict arise between the general information contained in this publication and the contents of drawings or supplementary material, or both, the latter shall take precedence.



Page 2 of 17 Summary & Introduction

Introduction

The Southern States, Cole Type L outdoor side break switches are available in ratings from 8.3kV through 72.5 kV and through 2000 amperes. The Type L is suitable for all types of outdoor disconnecting and sectionalizing service and may be mounted horizontally upright, horizontally underhung, vertically, or angularly. These switches meet all applicable NEMA and ANSI standards.

The installation procedure for all mounting positions and operating schemes is similar and explained herein. A system of pipes, bearing, and adjustable length arms is utilized to open and close the switch from a ground level operator.

The instructions contained within this manual are necessary for the safe installation, maintenance, and operation of the Type L switch. A qualified person, familiar with this of type equipment, should carefully read and follow the instructions.

These instructions are intended to provide a general guideline for the installation, adjustment, and maintenance of the Type L switch. All details, equipment variations, and potential conditions may not be covered in this manual. Contact Southern States, LLC in the event conditions associated with a specific application are not sufficiently addressed.

All photographs and sketches in this manual are for illustration purposes only and may not be to scale. Refer to the Unit Assembly drawing or the Operating Mechanism drawing provided with each disconnect switch for specific details. During installation, it may be necessary to make adjustments other than those described in this manual. Contact your local representative or the factory if questions should arise.

Southern States After Sales and Service Department is available for field installation assistance along with providing parts support for all Southern States products.

Contact After Sales and Service at 770-946-4562, 7:30am-4:00pm EST Monday-Friday. After Hours: 770-946-4565

Distinctive signal words are used to indicate the degree of hazard that may be encountered by the user. Identification of the signal words and their definition follow:

A DANGER	Indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.
	Indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
WARNING	Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.



Ratings

Table 1: Ratings Table

RATINGS							
Maximum Voltage Rating (kV)							
8.3	15.5	27	38 48.3 72.5				
BIL (kV)							
95	110	150	200	250	350		

ADDITIONAL RATINGS				
Rated Power Frequency	60 Hz			
Continuous Current	1200A	2000A		
Short-Time Symmetrical Withstand (3 Sec.)	38 kA RMS	50 kA RMS		
Peak Withstand	99 kA	130 kA		
Ambient Temperature Rating	-40°C to +50°C Standard -50°C Optional			



Page 4 of 17 **Product Description**

Product Description

Typical Disconnect Switch

In general, installing a disconnect switch consists of the following:

- Mounting the insulators (F) to the switch base (A)
- Mounting the live parts (B) to the insulators •
- Mounting the switch base (A) to the structure •
- Installing operating mechanism components •
- Final adjustment or tuning •



- A Switch Base G – Contact Fingers D – Jaw Assembly B – Blade H – Hinge
 - E Jacking Bolts
- C Insulator Bearing F Insulator

Figure 1: Type L 69kV, 1600 amp



Page 5 of 17

Receiving, Handling & Storage

Receiving, Handling & Storage

Unpacking

Unpack the equipment and check for damages or material shortages immediately. The bill-of-material from the Unit Assembly (switch) and Operating Mechanism drawings should be used for this purpose. If damage or a shortage is noted, file a claim immediately with the carrier and contact the factory.

Storage

All components of the Cole Type L center break disconnect switch are suitable for outdoor use. Keep bearings out of standing water. Keep upright and support live parts with base. If a motor operator is furnished, be sure to connect the heater circuit using the provided external wiring, while the unit is in storage. Discard the wiring upon installation.

Typical crating is intended for storage less than 1 year. If long term storage is required please notify factory at time of order placement so that special crating can be used.



Page 6 of 17

Installation & Adjustment Procedures

Installation & Adjustment Procedures

Table 2: Recommended Tools and Torque Values

Recommended Tools & Values

Recommended Tools			
Туре	Sizes		
Hand Wrenches	15/16", 3/4",		
and/or Sockets	5/8", 9/16"		
Drill Bit	1/4"		

Recommended Torque Values			
Bolt/Nut size	Torque (Ft-lb)		
1/2"	50 (S. Steel)		
5/8"			
3/4"	127		
1"	286		



Page 7 of 17

Installation & Adjustment Procedures

Preferred Switch Assembly Method:

If Disconnect switch is shipped assembled on insulators, ignore steps 3 and 4 (below).

- 1. DO NOT CHANGE any factory setting unless directed to do so in this manual.
- 2. These switches may be assembled on the structure or assembled on the ground and hoisted to the structure, according to preference. *Exception: Vertically mounted switches should always be assembled on the ground.* When assembling the switches on the ground, so not attempt to make contact adjustments until the switch is mounted on the structure. When lifting these switches, LIFT BY THE BASE ONLY.
- 3. Mount the insulators to the base mounting plates as shown in **Figure 2**, using the bolts indicated in the field assembly bolt list (SF Drawing).



Figure 2: Insulator Attachment

4. Mount the live parts as shown in Figure 3. The mounting bolts are captive and already in place.





Figure 3: Mounting Live Parts





- 5. If the switch has been assembled on the ground, at this time mount it on the structure, lifting by the switch base only. Refer to the Op. Mech. Drawing; there may be differences in the poles that require that they be mounted in specific locations.
- 6. If possible, attach the conductors to the terminal pads at this time to avoid having to readjust the switch later due to stack deflection caused by conductor loads.
- 7. Check the main pivot bolt on the live part hinge to make sure it is tight.
- 8. Manually test operate checking for proper contact engagement. The blade should enter the jaw centrally with equal clearance top and bottom as shown in **Figure 4**. If any misalignment is noted, loosen the live part mounting bolts and shim as required with the stainless steel shims provided. It will be necessary to shim the bottom of the insulator to correct large misalignments. Loosen the insulator mounting bolts and insert shim between insulator and bearing or adaptor.



Figure 4: Blade Clearance (A=B)



9. When proper contact engagement is achieved, install the operating mechanism.



Page 9 of 17

Installation & Adjustment Procedures

Operating Mechanism

(See Operating mechanism drawings provided for details):

- 1. Lay out all op-mech parts and check them against the Operating Mechanism drawing billof-material.
- 2. To ensure that the bearing stops do not interfere with switch adjustments, loosen each open/close bearing stop and slide them out of the way.

Refer to the Operating Mechanism drawing and install all mounting brackets, bearings, bushings, pipe clevises, switch operating device, adjustable arm, reach rod, and other necessary components. Refer to **Figure 5**.



Figure 5: Typical Operating Arrangement

- 3. **Caution:** The pipe collar (above the vertical bearing) must support the entire weight of the vertical operating pipe. To prevent unnecessary component damage, **Do not allow the pipe to rest on the switch operating device.** Refer **to Figure 6**.
- 4. While installing the pipes and clevises that have piercing bolts/set screws, do not pierce the pipe until instructed. Tighten the piercing bolts such that they grip the pipe until all adjustments are made.
- 5. After mounting all op-mech components, match-mark all clevis connections, the adjustable arm, and the switch operating device's coupling, so that you can tell if slippage occurs during trial operations.



Final Switch Adjustments (Tuning):

 The operating mechanism is intended to fully open and fully close the disconnect switch by rotating the vertical operating pipe approximately 180° using an operator (manual or electrical). The interphase pipe controls the individual operation of each switch pole, using a push/pull control. The reach rod translates the motion of the vertical operating pipe to the interphase linkage. The adjustable arm controls the total amount of switch operation available.

For easiest adjustment start with the reach rod connected to the drive phase and the interphase pipe disconnected from the other two phases. Once the drive phase is properly adjusted, connect the interphase pipe and continue tuning the other two phases, one at a time.

- 2. Switch Operating Devices:
 - 2.1 Worm gear operator (HOGO High Output Geared Operator) (Optional)
 - 2.1.1. The operator handle is factory set to rotate clockwise to open the switch.
 - 2.1.2. The weight of the vertical operating pipe should be supported by pipe collar (**Figure 5**) by maintaining the 1/4 3/8" gap (**Figure 6**).
 - 2.1.3. When the switch is properly adjusted the operator handle should hang freely in both the open and closed positions to permit the use of a customer supplied padlock. Refer to **Figure 6**.
 - 2.1.4. **Caution:** Be aware that there is an adjustable stop on the operator. **Do not** over operate as damage will occur to the operator.



Figure 6: Type HOGO (High Output Geared Operator) Front View

- 2.2 Swing handle operator
 - 2.2.1 When the switch is properly adjusted the handle should hang vertically and free in both the open and closed positions to permit the use of a customer supplied padlock.





- 3 Worm gear operator (SEGO Safety Enhanced Gear Operator) (Optional)
 - 3.1 The weight of the vertical operating pipe should be supported by pipe collar by maintaining the $\frac{1}{4}$ "-3/8" gap.
 - 3.2 When the switch is properly adjusted the operator handle should hang freely in both the open and closed positions to permit the use of the customer supplied padlock.

A CAUTION Be aware that there is an adjustable stop on the operator. <u>Do not</u> over operate as damage will occur to the operator.



Figure 7: Type SEGO (Safety Enhanced Gear Operator)

- 3.3 Electrical motor operator
 - 3.3.1 Please refer to motor operator instruction manual for proper installation and setup.
 - 3.3.2 Use manual operation while completing switch setup.
 - 3.3.3 **Do not** electrically operate until all switch adjustments are complete. **ALWAYS** operate the motor operator decoupled first to ensure proper setup.
- 4 Preliminary Switch Settings:

4.1 Start with the disconnect switch and operating mechanism in the closed position.



- 4.1.1 The switch is in the fully closed position when the centerline of the male blade assembly is aligned with the centerline of the Female Blade Assembly.
- 4.2 Set the adjustable arm to the preliminary setting on the Operating Mechanism drawing, adjustment may be necessary to achieve proper operation.
- 4.3 Be sure that all stops have been loosened to prevent binding during test operations.
- 5 Final Adjustment:
 - 5.1 Before making any adjustments always check that none of the pinned joints have slipped. If slippage occurs, correct it and repeat the operation to verify that adjustment is really needed.
 - 5.2 Open the disconnect switch with the operator.
 - 5.3 The switch is in the fully open position when both blades are approximately 90° to the switch base.
 - 5.4 If the switch **does not** fully open before the operator reaches the fully open position, the adjustable arm radius is too short. Close the switch, match-mark the adjustable arm and the pipe clevis, and loosen the bolts on the adjustable arm and pipe clevis. Lengthen the adjustable radius arm approximately ¹/₄". Allow the pipe clevis to reposition itself the same ¹/₄". Refer to **Figure 8**.
 - 5.4.1 Test operate and readjust as necessary.
 - 5.5 If the switch is fully open before the operator reaches the fully open position, the adjustable arm radius is too long. Close the switch, match-mark the adjustable arm and the pipe clevis, and loosen the bolts on the adjustable arm and pipe clevis. Shorten the adjustable radius arm approximately ¼". Allow the pipe clevis to reposition itself the same ¼". Refer to **Figure 8**.
 - 5.5.1 Test operate and readjust as necessary.
 - 5.6 If the switch has too much toggle in either open or closed position, loosen the pipe clevis and adjust to allow for an even toggle amount in both positions.
 - 5.7 All poles of the fully adjusted disconnect switch should operate together, although a slight variance between poles is acceptable. The primary objective is for all poles to fully open and fully close. Minor adjustments of the inter-phase pipe clevises may be necessary for pole coordination.
 - 5.8 Setting Toggle:
 - 5.8.1 Toggle is obtained when the switch is in the either fully open or fully closed position and the connection point between the adjustable arm and pipe clevis has gone past the centerline of the vertical operating pipe. The operating linkage will snap past this point.
 - 5.8.2 If possible the switch should go into toggle in both the open and closed positions. This is not always possible, it is most important that the switch goes into toggle in the closed position to help prevent the disconnect switch from to opening during a fault condition.



Page 13 of 17

Installation & Adjustment Procedures



Figure 8: Adjustable Arm Assembly

5.9 Final Check:

- 5.9.1 Once all final adjustments are complete, be sure that all nuts are tightened to their specified torque (Refer to **Table 2**).
- 5.9.2 Apply a minimal amount of grease to the point of each piercing bolt and then tighten the bolt until it pierces the pipe wall. For heavy walled pipe, (schedule 80 or above, 3" or above) pre-drill the piercing bolt holes with a piercing bolt drill guide (provided) and a ¼" drill bit.
- 5.9.3 Position bearing stops to lightly touch, in both the open and closed positions.





Changing Disconnect Opening Direction

The following are instructions for making field modifications to the opening direction of the disconnect switch if it is determined that it is necessary. If parts or assistance are required please contact your Local Representative or Southern States Service Division, contact information provide on the back page.

If disassembly is required by these instructions *IT SHOULD BE PERFORMED ON THE GROUND*. If this is not possible, proper safety and handling techniques must be used by installation crew to prevent damage to the components or injury to personnel.

- 1. Horizontally mounted disconnect switches without ground switch
 - 1.1. The simplest way to change disconnect opening direction is to rotate the entire *disconnect switch and* operating mechanism 180 degrees. For visual reference to see what is affected simply rotate the operating mechanism drawing in your hand. You will notice that operating linkage will rotate to the opposite end of the disconnect switch and that the operator will rotate to the opposite structure leg (diagonally from its original location).
 - 1.2. Sling each switch phase and rotate the entire assembly on the structure 180 degrees.
 - 1.3. The switch operator will also need to be relocated. There are 2 options:
 - 1.3.1. Move the operator to the opposite leg, diagonally from its original location. This is the best option as it allows for the original setup to be maintained.
 - 1.3.2. Maintain the operator on the same side of the structure. Assemble the components using the alternate position arrangement shown on the operating mechanism drawing. NOTE on 4 Column structures the operator will be on the same side of the structure, but it MUST move to the opposite end of the structure to obtain proper operation.
- 2. All other disconnect mountings without ground switch PARTIAL DISASSEMBLY WILL BE REQUIRED
 - 2.1. Disconnect adjustment
 - 2.1.1. With the disconnect phase on the ground, open the switch by hand and secure the linkage in this position.
 - 2.1.2. Unbolt the female blade from the insulator. Place the blade in the closed position and reattach to the insulator. DO NOT move the switch linkage.
 - 2.1.3. Unbolt the male blade from the insulator. Place the blade in the closed position and reattach to the insulator. It will likely be necessary to allow the linkage to move toward the "new" OPEN direction to be able to reassemble.
 - 2.1.4. Minor adjustments maybe required to the operating rod (Refer to Error! Reference source not found.) to achieve proper open close operation as described in Section 2 above.
 - 2.2. Operator and Operating linkage adjustment
 - 2.2.1. Swing handle or Worm gear operator
 - 2.2.1.1. NOTE: Due to space constraints you may not be able to move the adjustable arm to the opposite side of the pipe (structure side). In these cases it is impossible to achieve CLOCKWISE handle rotation to OPEN using a swing handle. The worm gear



operator will have to be changed to achieve proper rotation. Please contact representative.

- 3. Leave the operator in the starting position as originally shown on the operating mechanism drawing.
- 4. To achieve CLOCKWISE handle rotation to OPEN you must attach the adjustable arm 180 degrees from its original setup. The pipe clevis will also need to be rotated to the opposite side of the adjustable arm (side closest to the structure) but with the radius of the clevis still pointing toward the disconnect switch. The adjustable arm will now rotate toward the structure instead of away from it.
- 5. Attach all other items as shown in the operating mechanism drawing.
- 6. If the mechanism was originally setup for PUSH to OPEN it has now been changed to PULL to OPEN and vice versa.
- 5 Horizontally mounted disconnect switches with EVG-1 ground switch PARTIAL DISASSEMBLY WILL BE REQUIRED. Please contact Local Representative or Southern States Service Division immediately. New brackets for the ground switch and a new main switch operator will be required to make this change.
 - 5.1 Disconnect adjustment
 - 5.1.1 With the disconnect phase on the ground, remove the ground switch and mounting bracket as a complete assembly.
 - 5.1.2 If the insulators have not been installed, unbolt the live parts from the switch bearings and flip the paddle arms on each bearing along the long axis of the switch base. Reinstall all items as described in section 1.
 - 5.1.3 If the insulators have been installed, unbolt the male and female blades from the insulator. Unbolt the insulators from the switch bearings and flip the paddle arms on each bearing along the long axis of the switch base. Reinstall all items as described in section 1.
 - 5.1.4 Minor adjustments maybe required to the operating rod (Refer to Error! Reference source not found.) to achieve proper open close operation as described in Section 2 above.
 - 5.2 Ground Switch Adjustment
 - 5.2.1 Rotate the ground switch jaw 180 degrees and reattach to disconnect blade.
 - 5.2.2 Install new support bracket to the switch base. The ground switch must be installed on the OPEN side of the disconnect. Adjust the jacking bolts on the bracket until ground switch fits properly into its jaw.
 - 5.3 Operator and Operating linkage adjustment
 - 5.3.1 Both operators must move to the opposite leg(s) of the structure directly across from their current position
 - 5.3.2 Operator
 - Setup operating linkages as shown in revised operating mechanism drawings that will be provided.
 - Please note that a new operator will be needed for the main switch. The ground switch operator is the same.



Page 16 of 17

Recommended Inspection Maintenance

Recommended Inspection Maintenance

Southern States' disconnect switches are designed to operate with minimum maintenance. While disconnecting switches are not readily serviced at frequent intervals, *periodic inspection is important for satisfactory operation and maximized overall life*. Frequency of inspection and maintenance depends on the installation site, weather, atmospheric conditions, experience of operating personnel, and any special operation requirements.

During operational testing, the switch should be opened and closed several times, if possible, to clean the contacts and free the moving parts. A visual inspection, when the switch is wet, or temperature scanning detector may indicate hot spots that could serve as potential sources of trouble. Directional microphones or ultrasonic detectors can be used to locate local corona sources on the switches which can be eliminated during normal switch maintenance.

NOTE

It is recommended that maintenance on these switches be performed in accordance with ANSI STANDARDS **C37.30.1-2011**. In addition, well-established live-line servicing and maintenance procedures may be used in accordance with user practices and local and OSHA regulations.

		Installation Tests	Patrolling Inspection 6-months	Routine 5 Year *	Periodic 10 Year *
Insulators	Contamination	Х	Х	Х	Х
	Damage	Х	Х	x	Х
Cabinet (if motor operator supplied)	Any loose parts on the floor of the cabinet?	х	x	x	x
	Wiring Secure	Х	Х	X	X
	Links Secure	Х	Х	х	Х
	Inspect Mechanism for loose parts	Х	Х	х	Х
	Heaters Energized	Х	Х	х	Х
	Door Seal	Х	Х	х	Х
Mechanical	Operational Tests	Х		x	X
Electrical	Contact Resistance	Х		x	X
Liveparts Inspection	Inspect Contacts	Х		X	Х
	Inspect Arcing Horns	Х		Х	Х

Table 3: Recommended Installation and Maintenance Table

*NOTE: Inspection/maintenance is suggested to be performed every two (2) years when installed in harsh environments with excessive airborne contaminants such as salt spray and industrial pollutants.



Recommended Inspection Maintenance

Patrolling Inspection (6 Months)

The patrolling inspection is a largely visual inspection on an energized unit in service. The frequency of the inspection is determined by the local conditions and policies of the owner of the equipment.

- Inspect the insulators for breaks, cracks, burns, or cement deterioration. Clean insulators particularly
 where abnormal conditions such as salt deposits, cement dust, or acid fumes exist to minimize possibility
 of a flashover.
- If an accompanying motor operator is supplied, check the cabinet for loose parts and ensure that all wiring is secure, the heater is energized, and the door is sealed.

Routine Inspection and Maintenance (5 year)

A DANGER

The disconnect switch must be de-energized, disconnecting from all electrical power sources before servicing.

- Perform patrolling inspection (above), checking insulators and cabinet
- Once the disconnect switch is de-energized, test operate the switch multiple times.
- Check the switch for alignment, contact pressure, eroded contacts, corrosion, and mechanical malfunction, replacing damaged or eroded components if necessary. If contact pitting is minor, smooth the surface with a clean, fine sandpaper. It is recommended to clean and reapply C5-A grease during any operation or maintenance cycle, as exposed surfaces (*such as contacts*) are vulnerable to environmental conditions and contaminants that can decrease the effectiveness of the grease over time. During reapplication, clean and wipe down the contact surfaces with a green Scotchbrite pad, reapply C5-A grease, and remove any excess grease until an evenly coated, thin film is present.
- Inspect arcing horns for signs of excessive arc damage and replace if necessary.
- Check blade lock or latch for adjustment.
- Inspect all live parts for scarring, gouging, or sharp points that could contribute to excessive radio noise and corona. Check corona balls and rings for damage that could impair effectiveness.
- Inspect interphase linkages, operating rods, levers, bearings, etc. to assure that adjustments are correct, all joins are tight, and pipes are not bent.
- Check for simultaneous closing of all blades and for proper seating in the closed position.
- Inspect and check all safety interlocks while testing for proper operation.

Periodic Inspection and Maintenance (10 year)

A DANGER

The disconnect switch must be de-energized, disconnecting from all electrical power sources before servicing.

• Follow instructions for 5-year Routine Inspection and Maintenance



30 Georgia Avenue Hampton, Georgia 30228 Phone: 770-946-4562 Fax: 770-946-8106 E-mail: <u>support@southernstatesllc.com</u> <u>http://www.southernstatesllc.com</u>

©2021 Southern States, LLC IB-107-Cole L-Rev6 02182021 Printed U.S.A.