



TYPE EC-1

Aluminum Center Side
Break
Disconnect Switch

For 38 – 362 kV Ratings

INSTALLATION &

INSTRUCTION

MANUAL


ATTENTION:

Southern States will begin supplying a portion of new operating mechanism designs with Rapid-Set clevises for orders designed after 9/1/23. If your Operating Mechanism print calls for Rapid-Set clevises (see image below for an example), please utilize the instructions on the following pages for all linkage adjustments. If not, please adhere to the standard instructions provided.





Please scan or use the link below for video instructions of Rapid-Set.
[Southern States Rapid Set Instructions](#)




STEP 1:

For operating mechanisms with drive pipe connected directly to the interphase pipe, skip ahead to Step 10.


STEP 2:

Install the auxiliary arm by aligning the straight edge of the arm with the center of the vertical pipe and bolting it into place using two of the provided mounting holes. Do this with the switch phase set to the full closed position as shown below.




STEP 3:

Install the adjustable arm with the radius "R" set to the recommended length provided in the operating mechanism drawings.




STEP 4:

Install the auxiliary arm Rapid-Set clevis and drive pipe. Ensure that roughly 12" of pipe extends beyond the adjustable arm clevis connection so that the pipe makes contact with the adjustable arm in the position shown. This may be the open or closed position depending on the job specific drawings. The pipe should contact the adjustable arm in this position.




STEP 5:

With the auxiliary arm properly aligned with the vertical pipe and the switch phase in the full closed position, pierce the pipe at both ends. **NOTE:** U-bolt style clevises require pre-drilling on all pipes thicker than SCH40. Drill guides are provided on the operating mechanism BOM when required. Pierce the adjustable arm clevis by hand tightening until it penetrates the pipe and continue until snug (note piercing screw may still have threads showing). Do not remove plastic caps from the Rapid-Set clevis at this time. To pierce the Rapid-Set clevis, tighten each piercing screw until the head contacts the aluminum extrusion. Do not over tighten.



STEP 6:


Begin to manually open the phase using the operator. Observe the phase closed and open stops during operation and modify the length of the adjustable arm as needed to provide the proper amount of travel. Lengthen the arm to add travel and shorten the arm to decrease travel. The mechanism should have sufficient toggle (spring load) during closed and open position. To balance the force at closed and open positions, adjust the length “L” of the Rapid-Set clevis by adjusting the four nuts shown below. Ensure that both the top and bottom sets are adjusted in equal increments.




STEP 7:

After the drive phase is adjusted to operate correctly, set all phases to full closed, and install the interphase pipe following the procedure below.


For switches driven by the center phase:




- a. With the interphase pipe centered and all clevises in place, pierce the interphase pipe at the locations shown. Do not remove plastic caps at this time.




- b. Adjust the timing of the two driven phases by adjusting the length "L" of each Rapid-Set clevis.




For switches driven by one of the end phases:




- a. With the interphase pipe centered and all clevises in place, pierce the interphase pipe with at the locations shown. Do not remove plastic caps at this time.



- b. Adjust the timing of the center phase by adjusting the length "L" of the Rapid-Set clevis attached to the drive phase.



- c. Set the timing of the last phase by adjusting the length “L” of the Rapid-Set clevis attached to the last phase.




STEP 8:

With all the phases adjusted, open and close the three phase assembly and inspect for proper operation. Once adjustments are finalized, pierce all remaining connections (switch operator, adjustable arm, etc).


STEP 9:

Each Rapid-Set clevis is provided with 2 extra piercing screws. These are for optional use. To install these, remove the plastic cover caps and install them as shown below. Note, adding these will restrict any additional adjustment. Remove them before making any adjustments and then reinstall them on the bottom side of the clevis.




STEP 10:

For Operating mechanisms with the drive pipe connected directly to the interphase pipe, start by installing the adjustable arm with the radius "R" set to the recommended length provided in the operating mechanism drawings.




STEP 11:

With all three switch phases set to the full closed position, assemble the interphase pipe as shown below. Be sure to center the pipe between all three connection points before piercing the connections shown in Step 12.




STEP 12:

With all three phases set to the full closed position and the interphase pipe centered, pierce the interphase pipe at the locations shown. Do not remove plastic caps at this time.





STEP 13:

Install the drive pipe clevis to the interphase pipe at distance "L" shown on the operating mechanism drawing. Insert the drive pipe through both the drive pipe Rapid-Set and adjustable arm clevis.



STEP 14:

With the adjustable arm and switch phases set to the full closed position, pierce the drive pipe at both ends.




STEP 15:

Adjust all stops on the outer two phases to ensure they are fully backed off. Begin to manually operate the three phase switch and focus on adjusting the center phase first. Adjust the length of the adjustable arm to get the correct amount of travel in the open and closed directions. The drive pipe Rapid-set should be used to balance the force in open and closed for the center phase.

STEP 16:

Set the timing of the outside phases by adjusting the length “L” of the Rapid-Set clevis attached to the last phase.




STEP 17:

With all the phases adjusted, open and close the three phase assembly and inspect for proper operation. Once adjustments are finalized, pierce all remaining connections (switch operator, adjustable arm, etc).

STEP 18:

Each Rapid-Set clevis is provided with 2 extra piercing screws. These are for optional use. To install these, remove the plastic cover caps and install them as shown below. Note, adding these will restrict any additional adjustment. Remove them before making any adjustments and then reinstall them on the bottom side of the clevis.



Safety Information

DANGER

IMPROPER HANDLING, INSTALLATION, OPERATION OR MAINTENANCE OF THIS EQUIPMENT MAY CAUSE IMMEDIATE HAZARDS WHICH WILL LIKELY RESULT IN SERIOUS PERSONNEL INJURY OR DEATH.

WARNING

The equipment covered by this publication must be handled, installed, operated and maintained by qualified persons who have direct knowledge and experience dealing with the hazards involved and are thoroughly trained in the handling, installation, operation and maintenance of high voltage transmission and distribution equipment. These instructions are meant for only such **Qualified Persons**. They are not intended to be a substitute for adequate training and experience in safety procedures for this type of equipment.

A **Qualified Person** is one who is trained in and has skills necessary:

- to read and comprehend this instruction book – understanding that these instructions are general in nature
- to accept personal responsibility to prepare and maintain an intrinsically safe work environment and maintain control of the work site to safeguard all persons present
- to develop and implement a proper rigging, lifting, and installation plan along with all safety precautions required to insure safe and proper lifting and installation of the equipment.
- to distinguish between energized and non energized parts
- to determine proper approach distances to energized parts
- to properly work with and around energized or de-energized equipment that may be pressurized with gas
- for proper use of personal protective equipment, insulating and shielding materials, insulated tools for working near energized and /or pressurized electrical equipment
- to recognize and take necessary precautions for the unique and dynamic conditions of site and specialized equipment to maintain a safe work environment during handling, installation, operation, and maintenance of high voltage switching equipment

The instructions in this manual are general guidelines for this type of equipment and not specific to the equipment supplied. Portions of it may not be applicable or may not have complete instructions for your specific equipment.

If you do not understand any part of these instructions or need assistance, contact Southern States Service Division at 770-946-4562 during normal business hours (EST) or 770-946-4565 after normal business hours.

LIMITED WARRANTY

Southern States, LLC ("SLLC") warrants only to the Warranty Holder (hereinafter defined as the "End User" or the "Immediate Purchaser", as applicable, pursuant to the terms and conditions of this Limited Warranty as set forth below), that the Product identified below will, upon shipment, be free of defects in workmanship and material for the applicable Warranty Period. The "Warranty Period" is that period of time during which this Limited Warranty is effective, and such period begins on the invoice date issued by SLLC for the Product, and continues until the earlier to occur of (1) the expiration of the Warranty Duration period, or (2) the Number of Operations, both as specified in the table below. If the Product is both purchased and installed within the United States or Canada, this Limited Warranty is granted to each end user of the Product who acquired the Product for its own use during the Warranty Period ("End User"). In all other situations, this Limited Warranty is granted only to the first purchaser of the Product ("Immediate Purchaser") from SLLC. No primary or remote purchaser or owner of the Product who is not a Warranty Holder may claim any benefit under this Limited Warranty, or any remedial promise included in this Limited Warranty. SLLC shall, upon prompt written notice from the Warranty Holder, correct a nonconforming Product by repair or replacement at the sole discretion of SLLC of the nonconforming Product or any part or component of a nonconforming Product necessary in SLLC's discretion to make such Product conforming. Any transportation charges, labor for removing, reinstalling the Product or part, and/or costs related to providing access to the Product shall be the responsibility of the Warranty Holder. Correction in this manner will constitute the Warranty Holder's exclusive remedy and fulfillment of all SLLC's liabilities and responsibilities hereunder. SLLC's duty to perform under this limited warranty may be delayed, at SLLC's sole option, until SLLC has been paid in full for all products purchased by the Warranty Holder. No such delay will extend the Warranty Period. If SLLC does not make such repair or replacement, SLLC's liability for damages on account of any claimed nonconformity will in no event exceed the purchase price of the Product in question. This Limited Warranty does not apply to any Product that has been disassembled, repaired, or altered by anyone other than SLLC. This Limited Warranty will not apply to any Product that has been subjected to improper or abnormal use of the Product. SLLC has no responsibility to repair or replace any Product or component thereof manufactured by another party, but SLLC will assign, to the extent assignable, to the Warranty Holder any manufacturers' warranty that applies to products and components not manufactured by SLLC.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES. THERE ARE NO OTHER EXPRESS, IMPLIED, OR STATUTORY WARRANTIES. ALL IMPLIED WARRANTIES WHICH MAY ARISE BY IMPLICATION OF LAW, OR APPLICATION OF COURSE OF DEALING OR USAGE OF TRADE, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT OR OTHERWISE ARE EXPRESSLY EXCLUDED. SLLC SHALL NOT BE LIABLE OR RESPONSIBLE FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, EXEMPLARY, SPECIAL, OR PUNITIVE DAMAGES, EVEN IF SLLC HAS BEEN ADVISED OF THE POSSIBILITY OF SAME. THE WARRANTY HOLDER IS SOLELY RESPONSIBLE FOR THE SUITABILITY OF THE PRODUCT FOR ANY PARTICULAR APPLICATION.

Product Purchased Region	Product Installed Region	Warranty Holder	Warranty Duration
U.S and Canada	U.S and Canada	End User	Five (5) Years
All Other Conditions		Immediate Purchaser	Earlier of 1 year from installation or 18 months from shipment

Southern States, LLC**Equipment Receipt, Installation, Use, Operation and Maintenance Terms****("Terms of Use")**

The purchaser ("Purchaser") of certain Equipment (the "Equipment") identified in the Instruction Manual accompanying these Terms of Use sold by Southern States, LLC ("Southern States"), by Purchaser's acceptance or Use of Equipment in any way, agrees to the Terms of Use set forth below (the word "Use" herein means receipt, testing, inspection, installation, operation, maintenance and otherwise handling the Equipment):

- Purchaser represents and warrants that it is fully qualified to Use the Equipment, and that it is a sophisticated user of the Equipment with a high level of expertise in the Use of the Equipment and Purchaser knows that Southern States is relying on Purchaser's sophistication and expertise with respect to the Equipment.
- The Purchaser will, within seven (7) days after receipt of the Equipment, inspect the Equipment and identify and notify Southern States in writing of any missing parts, damage or defects observed in the Equipment.
- The Purchaser will Use the Equipment, only in conformity with all manuals, data sheets and instructions provided by Southern States, and in keeping with sound engineering, utility and safety practice. Purchaser will at its own expense, provide all necessary labor, supplies, and facilities required to Use the Equipment.
 - The Purchaser may use its own personnel or engage a third party to Use the Equipment. The Purchaser shall insure that it only utilizes personnel who are fully qualified or certified by a reputable certification agency to Use the Equipment. In the event that Purchaser cannot find such qualified personnel, the Purchaser will notify Southern States and seek its advice to determine a mutually agreeable solution.
 - By separate agreement, Southern States may provide such services and the personnel to conduct such services in connection with the installation of the Equipment. In the event Southern States agrees to provide personnel to install, maintain, and operate the Equipment, such personnel will function only in an advisory capacity and shall have no responsibility for the supervision, or the quality or workmanship of such installation, maintenance, or operation of the Equipment.
- The Purchaser shall not install and operate the Equipment in a way such that a single point of Equipment failure leads to a cascading event or consequential damage to any person or property. Purchaser shall ensure redundancy in its system at all times. Purchaser acknowledges and agrees that electric service is by nature subject to interruptions due to Equipment failures and shall not agree to provide service free from the effects of Equipment failures.
- The Equipment will be maintained and inspected as provided by this instruction manual and in compliance with best industry practices, but in no event will the Equipment be inspected and tested less frequently than once in every 6 months.
- The Purchaser shall not repair, dismantle, or alter any of the Equipment without Southern States' written consent.
- Any failure of Equipment either in service, testing or inspection will be promptly reported in writing to Southern States within 24 hours of the failure so that adequate evidence can be collected, appropriate diagnostic tests can be conducted, and analysis of the failure can be determined.
- Southern States will have no liability for any direct, indirect, consequential or remote damage or injury, whether or not foreseen or foreseeable, to the Purchaser or any third party or person for any damages or injury to person or property caused by Purchaser's or any third party's actions, whether or not negligent, in the Use of the Equipment. Purchaser shall indemnify and hold Southern States and its employees, officers and directors against any damage or injury caused in whole or part by Purchaser's or any third party's action whether or not negligent, resulting from the Use of the Equipment. Southern States expressly rejects any liability to third parties. The Purchaser expressly waives any claim against Southern States, its employees, officers, directors and affiliates, for injury or damage to person or property resulting from Use of the Equipment not directly and solely caused by Southern States' negligence. For the purposes of clarity, Southern States shall not be liable, and be fully indemnified by the Purchaser, for the following related to the Equipment: normal wear and tear, excessive use and loading, improper interference or maintenance on the part of the Purchaser or third parties, incomplete or false information given by the Purchaser, inappropriate or improper Use, faulty operation, installation or start-up, faulty or careless handling, improper maintenance, use of unsuitable operating materials/substitute materials, defective construction work, hazardous ambient conditions unknown to the Purchaser, chemical, electro-chemical or electrical influences, changes to the subject of delivery made without Southern States consent.
- In the event that Southern States is found by a court of competent jurisdiction or a properly empaneled arbitral body to be liable to the Purchaser for any reason, Southern States shall be entitled to a reduction in the liability by taking into account the exceptions provided by statute, law, and any counterclaims Southern States may have against Purchaser.
- The failure of Purchaser to comply with these Terms of Use herein shall void any and all warranties related to the Equipment. These Terms of Use shall be deemed to be part of the binding contractual agreements between Purchaser and Southern States related to the Equipment and shall govern over any inconsistent term or provision in such other contractual agreements.

Type EC-1



Table of Contents

Chapter	Page
Table of Contents	VIII
List of Tables and Figures	IX
Summary & Introduction	1
Summary	1
Important	1
Introduction	2
Introduction	2
Ratings	3
Product Description	4
Typical Disconnect Switch	4
Receiving, Handling & Storage	5
Unpacking	5
Storage	5
Installation & Adjustment Procedures	6
Recommended Tools & Values	6
General Information & Mandatory Pre-Installation Requirements	6
Preferred Switch Assembly Method	7
Live Part Installation & Contact Adjustment	12
Mounting disconnect switch onto the structure	15
Optional Accessories	16
Operating Mechanism	18
Final Switch Adjustments (Tuning)	19
Changing Disconnect Opening Direction	24
Recommended Inspection Maintenance	26
Patrolling Inspection (6 Months)	27
Routine Inspection and Maintenance (5 year)	27
Periodic Inspection and Maintenance (10 year)	27
Inspection Checklist	28

List of Tables and Figures

Tables Page

Table 1: Ratings Table	3
Table 2: Recommended Tools and Torque Values	6
Table 3: Minimum Opening.....	22
Table 4: Recommended Installation and Maintenance Table.....	26

Figures Page

Figure 1: Typical EC-1 Switch Pole Assembled & Common Terminology	4
Figure 2: Match-Marked Components (69kV bearing)	7
Figure 3: Match-Marked Components (69kV bearing)	8
Figure 4: Insulator Stack Alignment (72.5kV Bearing).....	9
Figure 5: Insulator Stack Alignment (230kV Bearing).....	9
Figure 6: Marker Placement	10
Figure 7a: Insulator Adjustment (1).....	11
Figure 7b: Insulator Adjustment (2).....	11
Figure 8: Switch - Fully Closed Position (Left – Side View, Right – Top View)	12
Figure 9: Blade Contact Adjustment	12
Figure 10: Blade Stops (123kV Bearing).....	13
Figure 11: Blade Stops (245kV Bearing).....	13
Figure 12: Hinge assembly of 4000/5000A	14
Figure 13: Insulator Stack Adjustment for Various Mounting Positions (69kV Bearing).....	15
Figure 14: Insulator Stack Adjustment for Various Mounting Positions (230kV Bearing).....	15
Figure 15: Sling Attachment	16
Figure 16: Seismic Blade Lock	17
Figure 17: Typical Operating Arrangement.....	18
Figure 18: Type HOGO (High Output Geared Operator) Front View	19
Figure 19: Type SEGO (Safety Enhanced Gear Operator) Front View	20
Figure 20: Switch - Fully Closed Position (Left: Side view, Right: Top view)	21
Figure 21: Switch – Fully Open Position (Top View)	22
Figure 22: Adjustable Arm Assembly	23

Summary & Introduction

Summary & Introduction

Summary

These instructions do not intend to cover all details or variations in equipment, or provide for every possible contingency to be met in connection with installation, operation or maintenance. Should information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local Southern States Representative.

The contents of this instruction manual should not become part of or modify any prior or existing agreement, commitment or relationship. The sales contract contains the entire obligations of Southern States. The Warranty contained in the contract between the parties is the sole warranty of Southern States. Any statements contained herein do not create new warranties or modify the existing warranty.

Important

The information contained herein is general in nature and not intended for specific application purposes. It does not relieve the user of responsibility to use sound practices in application, installation, operation, and maintenance of the equipment purchased. Southern States reserves the right to make changes in the specifications shown herein or to make improvements at any time without notice or obligations. Should a conflict arise between the general information contained in this publication and the contents of drawings or supplementary material, or both, the latter shall take precedence.

Summary & Introduction

Introduction

Southern States Type EC-1 is a three phase, group operated, center side break air disconnect switch constructed primarily of high strength aluminum. Applications for these switches included disconnecting and sectionalizing of lines, and isolating or bypassing other electrical equipment. Poles can be mounted in a horizontal “upright,” vertical, or under-hung position. The switch can be operated using a manual operator or electrical motor operator (Operating Mechanism).

For easy installation, all models use jack screws which provide infinite adjustments and eliminate time consuming shimming of insulator stacks.

The installation procedure for all mounting positions and operating schemes is similar and explained herein. A system of pipes, bearing, and adjustable length arms is utilized to open and close the switch from a ground level operator.

The instructions contained within this manual are necessary for the safe installation, maintenance, and operation of the EC-1 switch. A qualified person, familiar with this of type equipment, should carefully read and follow the instructions.

These instructions are intended to provide a general guideline for the installation, adjustment, and maintenance of the EC-1 switch. It is not possible to cover all details, equipment variations, and potential conditions. Contact Southern States, LLC in the event conditions associated with a specific application are not sufficiently addressed.

All photographs and sketches in this manual are for illustration purposes only and may not be to scale. Refer to the Unit Assembly drawing or the Operating Mechanism drawing provided with each disconnect switch for specific details. During installation, it may be necessary to make adjustments other than those described in this manual. Contact your local representative or the factory if questions should arise.

Southern States After Sales and Service Department is available for field installation assistance along with providing parts support for all Southern States products.

Contact After Sales and Service at 770-946-4562, 7:30am-4:00pm EST Monday-Friday.
After Hours: 770-946-4565

Distinctive signal words are used to indicate the degree of hazard that may be encountered by the user. Identification of the signal words and their definition follow:

▲ DANGER

Indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.

▲ CAUTION

Indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

▲ WARNING

Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.

Summary & Introduction

Ratings

Table 1: Ratings Table

RATINGS							
Maximum Voltage Rating (kV)							
38	48.3	72.5	123	145	170	245	362
BIL (kV)							
200	250	350	550	650	750	900/1050	1050/1300


ADDITIONAL RATINGS				
Rated Power Frequency	60 Hz			
Continuous Current	1200 A	2000 A – 3000 A	4000 A	5000 A
Short-Time Symmetrical Withstand (3 Sec.)	38 kA RMS	63 kA RMS	75 kA RMS	80 kA RMS
Peak Withstand	99 kA	164 kA	195 kA	208 kA
Ambient Temperature Rating	-40°C to +50°C Standard -50°C Optional			

Product Description

Typical Disconnect Switch

In general, installing a disconnect switch consists of the following:

- Mounting the insulators (F) to the switch base (A) (Refer to **Preferred Switch Assembly Method**).
- Mounting the live parts (G & I) to the insulators (Refer to **Live Part Installation & Contact Adjustment**).
- Mounting the switch base (A) to the structure (Refer to the **Operating Mechanism Drawings** for structure and mounting details)
- Installing operating mechanism components
- Final adjustment or tuning (Refer to **Final Switch Adjustments (Tuning)**).
- Mounting the switch base (A) to the structure (Refer to the **Operating Mechanism Drawings** for structure and mounting details)
- Installing operating mechanism components
- Final adjustment or tuning (Refer to **Final Switch Adjustments (Tuning)**).



A – Switch Base	F – Insulator	K – Terminal Pad
B – Bearing Stop	G – Female Blade Assembly	L – Operating Rod
C – Insulator Bearing	H – Hinge	M – Switch Operating Arm
D – Inter-Pole Arm	I – Male Blade Assembly	N – Locking Mechanism
E – Jacking Bolts	J – Contact Fingers	O – Contact Bar

Figure 1: Typical EC-1 Switch Pole Assembled & Common Terminology
(Corona Rings are for 245kV and above and are not shown.)

Receiving, Handling & Storage

Receiving, Handling & Storage

Unpacking

Unpack the equipment and check for damages or material shortages immediately. The bill-of-material from the Unit Assembly (switch) and Operating Mechanism drawings should be used for this purpose. If damage or a shortage is noted, file a claim immediately with the carrier and contact the factory.

Storage

All components of the EC-1 aluminum center side break disconnect switch are suitable for outdoor use and do not have any special storage requirements. Keep bearings out of standing water. Keep upright and support live parts with base. If a motor operator is furnished, be sure to connect the heater circuit using the provided external wiring, while the unit is in storage. Discard the wiring upon installation.

Typical crating is intended for storage less than 1 year. If long term storage is required please notify factory at time of order placement so that special crating can be used.

Installation & Adjustment Procedures

Installation & Adjustment Procedures

Recommended Tools & Values

Table 2: Recommended Tools and Torque Values

Recommended Tools		Recommended Torque Values	
Type	Sizes	Bolt/Nut size	Torque (Ft-lb)
Hand Wrenches and/or Sockets	15/16", 3/4", 5/8", 9/16"	1/2"	50 (S. Steel) 40 (All Others)
Drill Bit	1/4"	5/8"	92
		3/4"	127
		1"	286

General Information & Mandatory Pre-Installation Requirements

All photographs and sketches in this manual are for illustration purposes only and may not be to scale. Refer to the Unit Assembly drawing or the Operating Mechanism drawing provided with each disconnect switch for specific details on switch opening direction and handle location(s). *During installation, it may be necessary to make adjustments other than those described in this manual.* Contact your local representative or the factory if questions should arise.

Southern States Service Department is available for field installation assistance along with providing parts support for all Southern States products.

Contact the Service Department at 770-946-4562.

Installation & Adjustment Procedures

Preferred Switch Assembly Method

1. If Disconnect switch is shipped assembled on insulators Skip this section and continue to next section (**Error! No bookmark name given.**).
2. Assemble the switch pole on the ground and hoist it to the structure as a complete unit. **CAUTION:** To prevent overturning during assembly, the switch base must be securely attached to a level, stable platform. **CAUTION:** Lift fully assembled pole unit by the base only. **DO NOT lift the pole unit by the live parts.** Refer to **Figure 16**.
3. Before disassembling the live parts from the switch base you must match mark each of the parts indicated to ensure correct re-assembly. Match-mark A to B and B to C as shown in **Figure 2**. **Rotate seismic blade lock assembly 90 degrees to prevent interference during operation.** Failure to complete this step will make final adjustment more difficult.
4. Remove the switch live parts from the shipping spacer (painted red) [if provided], insulator bearings, and inter-pole arms. Make sure to save and reuse hardware if required by the Unit Assembly drawing.
 - 4.1. While it is typically not necessary to disconnect the operating rod from the inter-pole arm (Refer to **Figure 1**), if it must be disconnected match mark it first. *Failure to complete this step will remove the factory adjustment.*
5. Mount the insulator to the inter-pole arm and then to the bearing. Confirm match marks are aligned and properly torque the bolts (see **Table 2**).
6. Confirm proper insulator alignment, both insulators must be as near to perpendicular as possible to both the long and short axis of the disconnect switch base. **NOTE:** The original insulator stack height must be maintained. When the nuts on the jack bolts are used to adjust insulator tilt, opposite nuts must be turned equally (run one nut up a certain number of turns, turn the opposite nut down the same number of turns). Refer to **Figure 4** and **Figure 5**.




Figure 2: Match-Marked Components (Heavy Duty bearing)

A = Inter-pole Arm B = Bearing Hub C = Bearing

Installation & Adjustment Procedures




Figure 3: Match-Marked Components (Extra Heavy Duty bearing)

A = Inter-pole Arm B = Bearing Hub C = Bearing

- 1.1. Rotate the insulator to the closed position stop on the bearing.
- 1.2. Use a plumb bob or other straight line tool (e.g. laser level) to verify that the insulator is level.
- 1.3. If the insulator needs adjustment, use the nuts on the jack bolts of the insulator bearing to tilt the insulator in the needed direction. Refer to **Figure 4** and **Figure 5**.
- 1.4. **NOTE:** Vertically mounted **69kV** switches may require the following additional steps once mounted due to extra deflection, or sagging:

Refer to Figure 4:

Caution: Do not turn stud!

- i. Loosen all four "A" nuts.
- ii. Loosen both "C" nuts if provided.
- iii. Tilt insulator to necessary angle.
- iv. Adjust all four "B" nuts (up or down) until proper alignment is achieved.
- v. Retighten nuts to proper torque.

Installation & Adjustment Procedures




Figure 4: Insulator Stack Alignment (Heavy Duty Bearing)




Figure 5: Insulator Stack Alignment (Extra Heavy Duty Bearing)
(A = Jacking Bolt, B = Jacking Nut, C = Adjustment Bolt)

Installation & Adjustment Procedures

6.5. When installing insulators on high capacity bearings, the insulators require special attention to ensure good switch operation. It may be necessary that the insulators rotate about their axis uniformly; that is, they do not WOBBLE as they rotate. This may become important due to irregularities in insulator's mounting faces. It is not unusual for an insulator to be out of alignment six inches or more. While this switch is designed to tolerate certain misalignment, the rotating insulators may be adjusted to reduce the wobble to 1/4" or less.

6.5.1. For plumbing refer to 6.1 and 6.2.

6.5.2. To true the insulators:

- Make a mark at the center of insulator cap.
- Make a marker of any convenient material; ie: metal angle
- Make a sharp pointer and attach it to one end of marker.




Figure 6: Marker Placement

(Front View)

(Top View)

- The pointer should be placed on the center of the insulator, and the marker on a support outside of insulator rotation.
- Rotate the insulator against a stop, and position the reference pointer over the center of insulator cap.
- Rotate the insulator to the opposite bearing stop, observe for concentricity.

Installation & Adjustment Procedures




Figure 7a: Insulator Adjustment (1)

Insulator rotates away

- If insulator wobbles, leave it at the same position in previous step. Use the jacking screws, and tilt the insulator one-half the distance toward the reference point.




Figure 8b: Insulator Adjustment (2)

Tilt Insulator Half way

- Bring the bearing back to beginning position step.
- Repeat previous steps for all insulators (if necessary).

The above method can be used to adjust insulator rotation Axially, Laterally or combination of both.

Installation & Adjustment Procedures

Live Part Installation & Contact Adjustment

1. Rotate bearing slightly to open, mount the male and female blade assemblies on top of the insulators using the hardware indicated on the Unit Assembly drawing (see **Table 2**).
 - Confirm that switch is oriented properly, per the unit assembly drawing.
 - Confirm that the match marks are aligned before tightening hardware.
 - If corona rings are provided, refer to the Unit Assembly drawing for installation location
2. Back off the Blade Stops (Refer to **Figure 11**) on two insulator stacks, and turn Seismic Blade Lock, if provided, ninety (90) degrees so the Blade Lock is disengaged. Refer to **Figure 17**
3. With the male and female blade assemblies in the closed position verify, using a level, that both blades are in the same plane and that their centerlines are aligned. A slight variance is acceptable provided that the male contact is approximately perpendicular in the female contacts. Refer to **Figure 11**.
4. If contact adjustment is necessary, various sizes of stainless steel shims are provided for adjustment. Insert the shims between the insulator end cap and blade hinge until proper alignment is achieved. Torque the bolts to proper value (see
5. **Table 2**). Refer to **Figure 10**.




Figure 9: Switch - Fully Closed Position (Left – Side View, Right – Top View)




Figure 10: Blade Contact Adjustment

6. The male blade assembly should touch the blade stops as shown in **Figure 9**. If adjustment is necessary to achieve contact, loosen the bolts that attach the blades to the insulators, and

Installation & Adjustment Procedures

use the bolt hole tolerances to adjust the spacing. If a gap is still present (**Figure 9**), utilize the insulator stack adjusting bolts to adjust further (Refer to **Figure 4** and **Figure 5**). Torque all bolts to the recommended value(s) shown in **Table 2**.

7. Contact fingers should be centered or as close as possible on contact bar. All contact fingers must make contact with silver on contact bar in closed position as shown in **Figure 9**.
8. Use only DRIVING phase stop to set up the switch, with the other two stops completely backed off, then adjust the crank arm stop or rest within 1/4" inch of the blade stops (Refer to **Figure 11**). If adjustment is necessary, loosen the nuts on the adjusting bolt and adjust the bolt until the distance between the blade stop and the stop is correct. Torque the nuts to proper value. (See **Table 2**)




Figure 11: Blade Stops (Heavy Duty Bearing)

A= Stop, B=Crank Arm stop, C= Adjusting bolt




Figure 12: Blade Stops (Extra Heavy Duty Bearing)

A= Stop, B=Crank Arm stop, C= Adjusting bolt

Open Position (Seismic Stop Adjustment – Overall Length = 2")

Installation & Adjustment Procedures

9. Special adjustments have been built into 4000 & 5000 ampere switches. When assembled, CL of insulator and CL of rotating hinge shaft should be collinear (**Figure 13**). Blade closing can be adjusted by increasing or decreasing blade penetration, if needed. The following steps should be followed on both male and female blades:
 - 8.1. Loosen U-bolts on both blades.
 - 8.2. Slide blades for proper engagement, see figure 6.
 - 8.3. Tighten one U-bolt on each blade and check the closing sequence.
 - 8.4. Repeat steps 2.6.1 thru 2.6.3 until proper closing is achieved.
 - 8.5. Tighten all U-bolt nuts.




Figure 13: Hinge assembly of 4000/5000A

Installation & Adjustment Procedures

Mounting disconnect switch onto the structure

1. Recheck the Operating Mechanism drawing to confirm the correct position of the disconnect switch pole on the structure.
2. With the switch closed, secure the male and female blade assemblies using rope or other type of strap, to avoid movement during lifting.
3. Secure the switch arm to the bearing stop prior to lifting.
4. Lift the assembled switch by the switch base only. Refer to **Figure 16**.
5. Mount the disconnect switch to the structure using the hardware indicated by the Operating Mechanism drawing (see **Table 2**).
6. **If possible** mount the conductors to both ends of the switch pole before adjusting switches.
7. Conductor loads can alter fine switch adjustments, so final adjustments should not be performed prior to connecting the conductors.
8. Verify that the insulators are still properly aligned.
- 8.0. Refer to **Figure 5**, **Figure 14** and **Figure 15**. Adjust both “A” nuts and “B” nuts equally to prevent misalignment.
- 8.1. After adjustment, torque the nuts properly (see
- 8.2. **Table 2**).




Figure 14: Insulator Stack Adjustment for Various Mounting Positions (Heavy Duty Bearing)




Figure 15: Insulator Stack Adjustment (Extra Heavy Duty Bearing)

(A = Jacking Bolt, B = Jacking Nut, C – Adjustment Bolt)

Installation & Adjustment Procedures




Figure 16: Sling Attachment

Optional Accessories

1. Seismic Blade Lock (if equipped):

In the closed position the seismic blade lock hook should engage the locking post without touching it. There should be a $\frac{1}{2}$ " clearance between the locking hook and locking post. Refer to **Figure 17**. If adjustment is necessary, loosen both nuts on the locking hook and rotate the locking hook clockwise while holding the outside nut stationary to decrease the distance between the locking hook and locking post, or counterclockwise to increase the distance. The specified $\frac{1}{2}$ " clearance should not be exceeded.

2. Arcing Horns (if equipped):

2.1. Refer to the Unit Assembly drawing for necessary hardware and installation location.

2.2. Arcing horns should rub together with sufficient pressure to maintain contact, but not to cause binding.

2.3. Arcing horns should be touching before switch contacts separate from each other. If necessary the arcing horn can be bent to achieve proper contact.

Installation & Adjustment Procedures




Figure 17: Seismic Blade Lock

Installation & Adjustment Procedures

Operating Mechanism (See Operating mechanism drawings provided for details)

1. Lay out all Operating Mechanism parts and check them against the Op-Mech drawing bill-of-material.
2. To ensure that the bearing stops do not interfere with switch adjustments, loosen all open/close bearing stops, and slide them out of the way.
3. Refer to the Operating Mechanism drawing, and install all mounting brackets, bearings, bushings, pipe clevises, switch operating device, adjustable arm, reach rod, and other necessary components. Refer to **Figure 18**.

⚠ CAUTION The pipe collar (above the vertical bearing) must support the entire weight of the vertical operating pipe. To prevent unnecessary component damage, **Do not allow the pipe to rest on the switch operating device**. Refer to **Figure 18**.

4. While installing the pipes and clevises that have piercing bolts/set screws, do not pierce the pipe until instructed. Tighten the piercing bolts such that they grip the pipe until all adjustments are made.
5. After mounting all op-mech components, match-mark all clevis connections, the adjustable arm, and the switch operating devices' coupling, so that any slippage occurring during trial operations can be readily detected. Refer to **Figure 18**.




Figure 18: Typical Operating Arrangement

Installation & Adjustment Procedures

Final Switch Adjustments (Tuning)

1. The operating mechanism is intended to fully open and fully close the disconnect switch by rotating the vertical operating pipe about 180° using an operator (manual or electrical). The interphase pipe controls the individual operation of each switch pole, using a push/pull control. The reach rod translates the motion of the vertical operating pipe to the interphase linkage. The adjustable arm controls the total amount of switch operation available.

HINT: For easiest adjustment start with the reach rod connected to the drive phase and the interphase pipe disconnected from the other two phases. Once the drive phase is properly adjusted, connect the interphase pipe and continue tuning the other two phases, one at a time.

2. Switch Operating Devices:

- 2.1. Worm gear operator (HOGO – High Output Geared Operator) (Optional)

- 2.1.1. The operator handle is factory set to rotate clockwise to open the switch.

- 2.1.2. The weight of the vertical operating pipe should be supported by pipe collar (**Figure 18**) by maintaining the 1/4 - 3/8" gap (**Figure 19**).

- 2.1.3. When the switch is properly adjusted the operator handle should hang freely in both the open and closed positions to permit the use of a customer supplied padlock. Refer to **Figure 19**.

⚠ CAUTION Be aware that there is an adjustable stop on the operator. **Do not over operate as damage will occur to the operator.**




Figure 19: Type HOGO (High Output Geared Operator) Front View

2.2. Worm gear operator (SEGO – Safety Enhanced Gear Operator) (Optional)

2.2.1. The weight of the vertical operating pipe should be supported by pipe collar (**Figure 20**) by maintaining the 1/4"-3/8" gap.

2.2.2. When the switch is properly adjusted the operator handle should hang freely in both the open and closed positions to permit the use of the customer supplied padlock. Refer to **Figure 20**.

CAUTION

Be aware that there is an adjustable stop on the operator. Do not over operate as damage will occur to the operator.




Figure 20: Type SEGO (Safety Enhanced Gear Operator)

2.3. Swing handle operator

2.3.1. When the switch is properly adjusted the handle should hang vertically and free in both the open and closed positions to permit the use of a customer supplied padlock.

2.4. Electrical motor operator

2.4.1. Please refer to motor operator instruction manual for proper installation and setup.

2.4.2. Use manual operation while completing switch setup.

2.4.3. **Do not** electrically operate until all switch adjustments are complete. **ALWAYS** operate the motor operator decoupled first to ensure proper setup.

3. Preliminary Switch Settings:

3.1. Start with the disconnect switch and operating mechanism in the closed position. Refer to **Figure 21**.

3.1.1. The switch is in the fully closed position when the centerline of the male blade assembly is aligned with the centerline of the Female Blade Assembly.

3.2. Set the adjustable arm to the preliminary setting on the Operating Mechanism drawing, adjustment may be necessary to achieve proper operation.

3.3. Be sure that all stops have been loosened to prevent binding during test operations.




Figure 21: Switch - Fully Closed Position (Left: Side view, Right: Top view)

4. Final Adjustment:

4.1. Before making any adjustments always check that none of the pinned joints have slipped. If slippage occurs, correct it and repeat the operation to verify that adjustment is really needed.

4.2. Open the disconnect switch with the operator. The switch is in the fully open position when both blades are approximately 90° to the switch base. Refer to **Figure 22**.

4.3. If the switch **does not** fully open before the operator reaches the fully open position, the adjustable arm radius is too short. Close the switch, match-mark the adjustable arm and the pipe clevis, and loosen the bolts on the adjustable arm and pipe clevis. **Lengthen the adjustable radius arm approximately 1/4". Allow the pipe clevis to reposition itself the same 1/4".** Refer to **Figure 19**. Test operation and readjust as necessary.

4.4. If the switch is fully open before the operator reaches the fully open position, the adjustable arm radius is too long. Close the switch, match-mark the adjustable arm and the pipe clevis, and loosen the bolts on the adjustable arm and pipe clevis. **Shorten the adjustable radius arm approximately 1/4". Allow the pipe clevis to reposition itself the same 1/4".** Refer to **Figure 19**. Test operation and readjust as necessary.

4.5. If the switch has too much toggle in either open or closed position, loosen the pipe clevis and adjust to allow for an equal toggle amount in both positions.

4.6. All poles of the fully adjusted disconnect switch should operate together, although a slight variance between poles is acceptable. The primary objective is for all poles to fully open and

fully close. Minor adjustments of the inter-phase pipe clevises may be necessary for pole coordination.




Figure 22: Switch – Fully Open Position (Top View)

Switch Rating (kV)	Recommended Minimum Distance between any metal parts
72.5	32"
123	50
145	60
170	68
245 (900)	84
245 / 362 (1050)	104
362 (1300)	120

Table 3: Minimum Opening

4.7. Setting Toggle:

- 4.7.1. Toggle is obtained when the switch is in the either fully open or fully closed position and the connection point between the adjustable arm and pipe clevis has gone past the centerline of the vertical operating pipe. The operating linkage will almost seem to snap past this point.
- 4.7.2. If possible the switch should go into toggle in both the open and closed positions. This is not always possible, it is most important that the switch goes into toggle in the

closed position, because this will help to prevent the disconnect switch from trying to open during a fault condition.




Figure 23: Adjustable Arm Assembly

4.8. Final Check:

- 4.8.1. Once all final adjustments are complete, be sure that all nuts are tightened to their specified torque (Refer to
- 4.8.2. **Table 2**).
- 4.8.3. Apply a minimal amount of grease to the point of each piercing bolt and then tighten the bolt until it pierces the pipe wall. For heavy walled pipe, (schedule 80 or above, 3" or above) pre-drill the piercing bolt holes with a piercing bolt drill guide (provided) and a 1/4" drill bit.
- 4.8.4. Position bearing stops to lightly touch, in both the open and closed positions.

Changing Disconnect Opening Direction

The following are instructions for making field modifications to the opening direction of the disconnect switch if it is determined that it is necessary. If parts or assistance are required please contact your Local Representative or Southern States Service Division, contact information provide on the back page.

If disassembly is required by these instructions *IT SHOULD BE PERFORMED ON THE GROUND*. If this is not possible, proper safety and handling techniques must be used by installation crew to prevent damage to the components or injury to personnel.

1. Horizontally mounted disconnect switches without ground switch
 - 1.1. The simplest way to change disconnect opening direction is to rotate the entire **disconnect switch and** operating mechanism 180°. For visual reference to see what is affected simply rotate the operating mechanism 180° in your hand. You will notice that the operating linkage will rotate to the opposite end of the disconnect switch and that the operator will rotate to the opposite structure leg (diagonally from its original location).
 - 1.2. Sling each switch phase and rotate the entire assembly on the structure 180 degrees. Refer to **Figure 16**.
 - 1.3. The switch operator will also need to be relocated. There are 2 options:
 - 1.3.1. Move the operator to the opposite leg, diagonally from its original location. This is the best option as it allows for the original setup to be maintained.
 - 1.3.2. Maintain the operator on the same side of the structure. Assemble the components using the alternate position arrangement shown on the operating mechanism drawing. NOTE on 4 Column structures the operator will be on the same side of the structure, but it **MUST** move to the opposite end of the structure to obtain proper operation.
2. All other disconnect mountings without ground switch – PARTIAL DISASSEMBLY WILL BE REQUIRED
 - 2.1. Disconnect adjustment
 - 2.1.1. With the disconnect phase on the ground, open the switch by hand and secure the linkage in this position.
 - 2.1.2. Unbolt the female blade from the insulator. Place the blade in the closed position and reattach to the insulator. DO NOT move the switch linkage.
 - 2.1.3. Unbolt the male blade from the insulator. Place the blade in the closed position and reattach to the insulator. It will likely be necessary to allow the linkage to move toward the “new” OPEN direction to be able to reassemble.
 - 2.1.4. Minor adjustments maybe required to the operating rod to achieve proper open close operation as described in Section 2 above.
 - 2.2. Operator and Operating linkage adjustment
 - 2.2.1. Swing handle or Worm gear operator

NOTE: Due to space constraints you may not be able to move the adjustable arm to the opposite side of the pipe (structure side). In these cases it is impossible to achieve CLOCKWISE handle rotation to OPEN using a swing handle. The worm gear operator will have to be changed to achieve proper rotation. Please contact representative.

 - a Leave the operator in the starting position as originally shown on the operating mechanism drawing.

- b To achieve CLOCKWISE handle rotation to OPEN you must attach the adjustable arm 180 degrees from its original setup. The pipe clevis will also need to be rotated to the opposite side of the adjustable arm (side closest to the structure) but with the radius of the clevis still pointing toward the disconnect switch. The adjustable arm will now rotate toward the structure instead of away from it.
 - c Attach all other items as shown in the operating mechanism drawing.
 - d If the mechanism was originally setup for PUSH to OPEN it has now been changed to PULL to OPEN and vice versa.
- 3. Horizontally mounted disconnect switches with EVG-1 ground switch – PARTIAL DISASSEMBLY WILL BE REQUIRED. Please contact Local Representative or Southern States Service Division immediately. New brackets for the ground switch and a new main switch operator will be required to make this change.
 - 3.1. Disconnect adjustment
 - 3.1.1. With the disconnect phase on the ground, remove the ground switch and mounting bracket as a complete assembly.
 - 3.1.2. If the insulators have not been installed, unbolt the live parts from the switch bearings and flip the paddle arms on each bearing along the long axis of the switch base. Reinstall all items as described in **Preferred Switch Assembly Method**.
 - 3.1.3. If the insulators have been installed, unbolt the male and female blades from the insulator. Unbolt the insulators from the switch bearings and flip the paddle arms on each bearing along the long axis of the switch base. Reinstall all items as described in **Preferred Switch Assembly Method**.
 - 3.1.4. Minor adjustments maybe required to the operating rod to achieve proper open close operation as described in Section 2 above.
 - 3.2. Ground Switch Adjustment
 - 3.2.1. Rotate the ground switch jaw 180 degrees and reattach to disconnect blade.
 - 3.2.2. Install new support bracket to the switch base. The ground switch must be installed on the OPEN side of the disconnect. Adjust the jacking bolts on the bracket until ground switch fits properly into its jaw.
 - 3.3. Operator and Operating linkage adjustment
 - 3.3.1. Both operators must move to the opposite leg(s) of the structure directly across from their current position
 - 3.3.2. Operator
 - a Setup operating linkages as shown in revised operating mechanism drawings that will be provided.
 - b Please note that a new operator will be needed for the main switch. The ground switch operator is the same.

Recommended Inspection Maintenance

Recommended Inspection Maintenance

Southern States' disconnect switches are designed to operate with minimum maintenance. While disconnecting switches are not readily serviced at frequent intervals, *periodic inspection is important for satisfactory operation and maximized overall life*. Frequency of inspection and maintenance depends on the installation site, weather, atmospheric conditions, experience of operating personnel, and any special operation requirements.

During operational testing, the switch should be opened and closed several times, if possible, to clean the contacts and free the moving parts. A visual inspection, when the switch is wet, or temperature scanning detector may indicate hot spots that could serve as potential sources of trouble. Directional microphones or ultrasonic detectors can be used to locate local corona sources on the switches which can be eliminated during normal switch maintenance.

NOTE

It is recommended that maintenance on these switches be performed in accordance with ANSI STANDARDS **C37.30.1-2011**. In addition, well-established live-line servicing and maintenance procedures may be used in accordance with user practices and local and OSHA regulations.

Table 4: Recommended Installation and Maintenance Table

		Installation Tests	Patrolling Inspection 6-months	Routine 5 Year *	Periodic 10 Year *
Insulators	Contamination	X	X	X	X
	Damage	X	X	X	X
Cabinet (if motor operator supplied)	Any loose parts on the floor of the cabinet?	X	X	X	X
	Wiring Secure	X	X	X	X
	Links Secure	X	X	X	X
	Inspect Mechanism for loose parts	X	X	X	X
Mechanical	Heaters Energized	X	X	X	X
	Door Seal	X	X	X	X
	Operational Tests	X		X	X
Electrical	Contact Resistance	X		X	X
Liveparts Inspection	Inspect Contacts	X		X	X
	Inspect Arcing Horns	X		X	X

***NOTE:** Inspection/maintenance is suggested to be performed every two (2) years when installed in harsh environments with excessive airborne contaminants such as salt spray and industrial pollutants.

Recommended Inspection Maintenance

Patrolling Inspection (6 Months)

The patrolling inspection is a largely visual inspection on an energized unit in service. The frequency of the inspection is determined by the local conditions and policies of the owner of the equipment.

- Inspect the insulators for breaks, cracks, burns, or cement deterioration. Clean insulators particularly where abnormal conditions such as salt deposits, cement dust, or acid fumes exist to minimize possibility of a flashover.
- If an accompanying motor operator is supplied, check the cabinet for loose parts and ensure that all wiring is secure, the heater is energized, and the door is sealed.

Routine Inspection and Maintenance (5 year)



The disconnect switch must be de-energized, disconnecting from all electrical power sources before servicing.

- Perform patrolling inspection (above), checking insulators and cabinet
- Once the disconnect switch is de-energized, test operate the switch multiple times.
- Check the switch for alignment, contact pressure, eroded contacts, corrosion, and mechanical malfunction, replacing damaged or eroded components if necessary. If contact pitting is minor, smooth the surface with a clean, fine sandpaper. It is recommended to clean and reapply C5-A grease during any operation or maintenance cycle, as exposed surfaces (*such as contacts*) are vulnerable to environmental conditions and contaminants that can decrease the effectiveness of the grease over time. During reapplication, clean and wipe down the contact surfaces with a green Scotchbrite pad, reapply C5-A grease, and remove any excess grease until an evenly coated, thin film is present.
- Inspect arcing horns for signs of excessive arc damage and replace if necessary.
- Check blade lock or latch for adjustment.
- Inspect all live parts for scarring, gouging, or sharp points that could contribute to excessive radio noise and corona. Check corona balls and rings for damage that could impair effectiveness.
- Inspect interphase linkages, operating rods, levers, bearings, etc. to assure that adjustments are correct, all joins are tight, and pipes are not bent.
- Check for simultaneous closing of all blades and for proper seating in the closed position.
- Inspect and check all safety interlocks while testing for proper operation.

Periodic Inspection and Maintenance (10 year)



The disconnect switch must be de-energized, disconnecting from all electrical power sources before servicing.

- Follow instructions for 5-year Routine Inspection and Maintenance

Recommended Inspection Maintenance

Inspection Checklist

EC-1 TYPE DISCONNECT SWITCHES			
SUBSTATION NAME		POSITION	
SITE REP:		DATE:	
ACCEPTED BY QC:		DATE:	
INSTALLER:			
SAP NUMBER:		KV RATING:	
S.S. #		AMP RATING:	
INSTALLATION PER SOUTHERN STATES MANUAL			
	Installer	Site Rep	OC
Check for damage or material shortages (Page 1)			
All Nuts, Bolts and other hardware are Tight and Torque marked			
Pipe Collar supporting Vertical Drive Pipe (Refer to 6.2.1.2 Page 13)			
All Cotter Keys are Bent			
Blades Centered in The Clip (Figure 6 Page 6)			
Blades Closed Gap 3/4" to 1/4" (Figure 6 Page 6)			
Blades Closed & Aligned (Refer to 2.2 on Page 6)			
Blades Straight In Open Position (Figure 17 Page 14)			
Verify Contact Wipe - Timing (within 3/4")			
Open rotation Stops Engaged On Insulator Stack (Figure 9 Page 7)			
Closed rotation Stops factory set no adjustment required (Figure 10 Page 8)			
Verify Min. Gap On HOGO Handle 1/4 to 3/8 gap (Figure 16 Page 13)			
Blade Lock adjusted per (Figure 14 Page 11)			
Handle is 40 inches from grade (+/-) 3 inches			
Handle is Hanging Free (Refer to 6.2.1.3. on Page 13)			
Handle - Clockwise to Open			
Handle and Structure Ground Attached			
Handle Stop Touching in The Closed Position			
Handle Stop Touching In The Open Position			
Handle operating pressure less than 35 pounds of force			
Name Plate attached by handle			
Signs- Open & Closed Properly Installed			
Toggle in Closed Position (Refer to 6.4.7 on Page 14)			
Toggle in Open Position (Refer to 6.4.7 on Page 14)			
HOLD Point contact QC 48 Hours notice			
Piercing Bolts Set After Buy-off			

[illegible]



The Quality Name in High Voltage Switching

30 Georgia Avenue
Hampton, Georgia 30228
Phone: 770-946-4562
Fax: 770-946-8106
E-mail: support@southernstatesllc.com
<http://www.southernstatesllc.com>

©2021 Southern States, LLC
IB-136-EC-1 245-R7 02182021 Printed U.S.A.