



Information Required To Be Provided To Southern States At Time Of Order Placement When A Motor Operator Is Purchased To Operate An Existing Switch (A Southern States Switch Or The Switch Of Another Manufacturer) Or A New Switch From Another Manufacturer:

- (1) What is the source voltage for the motor operator?
- (2) What is the kV rating of the switch the motor operator is to drive?
- (3) What is the continuous current rating of the switch the motor operator is to drive?
- (4) What is the break type of the switch (vertical break, double end break, double end break V, center break, center break V, or single side break) the motor operator is to drive ?
- (5) What is the vertical operating pipe size in inches IPS? (If not stated a set up for 2 inch IPS will be assumed and supplied.)
- (6) What is the direction of output rotation to open the motor operator when viewed from above looking downward, clockwise to open or counterclockwise to open? (If not stated a set up for clockwise to open will be assumed and supplied.)
- (7) What is the degree of output rotation to open or to close the motor operator? (If not stated a set up for 180 degree output rotation will be assumed and supplied.)

Note: (6) and (7) above are field changeable (The directions on how to make these changes are in the instruction book which is supplied with the motor operator.); however, if the required information is known at time of purchase the correct direction and degree of operation can be factory set so that no field adjustments are necessary, thus minimizing the field installation time required. (5) is not field changeable and must be known at time of purchase.

**Southern States, LLC 30 Georgia Avenue Hampton, GA 30228 phone: 770-946-4562**  
**fax: 770-946-8106 e-mail: [sales@southernstatesLLC.com](mailto:sales@southernstatesLLC.com) website: [www.southernstatesLLC.com](http://www.southernstatesLLC.com)**

**The Quality Name in High Voltage Switching**