




Fuse Accessories



EXPENDABLE CAPS FOR DISTRIBUTION CUTOUTS

Spare caps for use on Southern States expendable cap cutouts are available. They are packed five to each carton.

CATALOG NO. FOR 100 AMP CUTOUTS	CATALOG NO. FOR 200 AMP CUTOUTS
BP-100	BP-200




TYPE JDM FOR FUSES RATED
7.2-23 KV



TYPE JDM FOR FUSES RATED
34.5-161 KV



TYPE JDM-45 FOR
45° UNDERHUNG FUSES



TERMINAL HOOKS

FUSE JUMPERS AND HOOKS FOR SOUTHERN STATES POWER FUSES

Southern States Type JDM or JDM-45 fuse jumpers allow inspection or replacement of elements of any power fuse without service interruption.

Fuses in service may be modified to permit its use by installing terminal hooks between fuse mounting hardware and insulator caps at jaw and hinge ends. These hooks are designed to engage with terminal rings located at each end of the spring loaded jumper. The Type JDM may be easily installed with any hookstick.

With fuse by-passed, fuse holder and link may be removed for inspection.

The JDM is not intended to be left in the circuit for a period longer than is necessary to change fuse holders or examine fuse links. It does not function as a fuse and *has no interrupting rating*.

The following is a tabulation showing the continuous current it will safely carry for a given period of time:

TIME (in hours)	AMPERES
1/6	200
1	125
2	100
Continuous	75

TYPE JDM FUSE JUMPERS

FUSE KV RATING	JUMPER CATALOG NO.
7.2-23	JDM7523
34.5	JDM340
46	JDM460
69	JDM690
88	JDM880
115	JDM115 *
138	JDM138 *
161	JDM161 *

*Add "A" to catalog number for use with Type HPA fuses.

TYPE JDM-45 JUMPERS

34.5	JDM4534
46	JDM4546
69	JDM4569
88	JDM4588
115	JDM45115 *
138	JDM45138 *
161	JDM45161 *

*Add "A" to catalog number for use with Type HPA fuses.

TERMINAL HOOKS

3" B.C.	JDMH3
5" B.C.	JDMH5